



Transpak

Operating Manual

Transpak Operating Manual—OM0007E/1

This manual contains important safety, installation and operating instructions for this unit. Read this manual thoroughly and completely, and retain for future reference. This unit can cause serious injury to personnel or damage to property if used incorrectly, therefore do not use this machine for any other purpose apart from its intended use. Using this unit incorrectly may void warranty.

Any damage audible or visible to this unit should be addressed at the time of discovery. Electrodrive Pty Ltd can provide parts and service support on request through its service partner company:

Serviced Equipment Pty Ltd

p: 1300 934 471

e: info@servicedequipment.com.au

Made in Australia by:

Electrodrive Pty Ltd

2A Ayton Street, North Sunshine VIC Australia 3020

p: 1800 333 002 (within Australia)

p: +61 (03) 9300 8521 (International)

e: sales@electrodrive.com.au

w: www.electrodrive.com.au

© Electrodrive

Contents

- Introduction..... 5**
 - Features 5
 - Controls 6
- Operating instructions 6**
 - Controls 7
- Driving instructions 9**
 - Safety check 9
 - Steering..... 9
 - Charging 9
- Maintenance 10**
 - Batteries..... 10
 - Motor and transmission..... 10
 - Brakes..... 10
 - Motor controller 10
 - Throttle lever 10
 - Fuses 10
 - Self-resetting circuit breaker..... 10
- Warranty 11**
 - Unauthorised maintenance..... 11
 - Misuse 11
 - General wear items not covered under warranty..... 11
- Appendix 1: Machine rating conditions..... 12**
- Appendix 2: Fault codes 13**
- Appendix 3: Charging procedures for SLA batteries 14**
 - Charging setup 14
 - During charging 14
 - Charger manual 14

Appendix 4: Spare parts list.....	15
Appendix 5: Wiring diagram	16
Service log	18

Introduction

Move your heavy equipment with the battery powered Transpak.

The Transpak converts your heavy equipment into a powerful, easy to move motorised trolley. Productivity is greatly increased, and back or shoulder strain is eliminated.


The Transpak allows an operator to effortlessly move heavy equipment:

- Through long corridors, factory aisles, round tight corners.
- Up and down ramps.
- On and off lifts.


Features

- Rated to tow up to 500 kg.
- 24 Volt DC power.
- Variable speed drive unit.
- Electro-magnetic park brake.
- Travel speed—up to 5 kph.
- Robust steel chassis.
- Tiller handle steering that folds up to reduce space when not in use.
- Programmable motor controller.
- Automatic charger.

Operating instructions



Controls



Controls

Key switch

The key switch must be turned clockwise to switch the unit on. When ON, the LED status indicator will be illuminated. If a fault occurs with the electronics, this LED light will flash an error code (refer to Appendix 2). It is important to note that the unit should be switched off and the key removed, whenever it is not in use. This eliminates the risk of unauthorised movement and also prevents an unnecessary use of battery power.

Emergency stop and back-off button

The controls have two emergency buttons.

1. Emergency stop button—in an emergency, push this button to stop the unit. To release, slightly twist the button and it will pop back up.
2. Emergency back-off button—when pressed, the unit will travel backwards until released, to avoid pinning the operator against an obstacle.



Only use the emergency buttons in an emergency.

Direction selector

This determines the direction of travel. Push the button corresponding to the desired travel direction (forward/reverse).

Throttle lever

This lever provides variable speed control from zero up to 100% of the governed speed. Releasing the lever stops the unit.

Speed selector

The speed selector will always start in the SLOW position. Select a speed that you are comfortable using. The speed can be changed whilst driving. It is advisable that you operate this unit at a slow speed when entering a confined area.

Battery level indicator

The battery level indicator indicates the amount of charge left in the batteries. When it appears to be running low, return the unit to the closest charging station to charge the batteries. Being aware of the level of charge of the batteries will eliminate the possibility of running low on power whilst away from the charging station. Red light only indicates no usable battery power remaining.

Horn (where fitted)

Push to sound the horn, release to turn off.

Charger socket

The charger socket is located on the body panel of the unit, next to the tiller post.

Brakes

When the speed control lever is released, the unit is slowed electrically by dynamic braking until the machine and load comes to a complete stop.

Capacity

Refer to the serial plate for the unit's safe working load, located on the body adjacent to the tiller post.

Driving instructions

Safety check

Before using the Transpak the operator should complete the following check:

1. The battery charger is not connected.
2. The direction selector works.
3. The emergency stop button is released.
4. The brakes operate correctly when the throttle lever is released.
5. The battery indicator shows adequate charge.
6. There is no visible damage to the unit.

Steering

The tiller arm provides easy steering. The Transpak can be manoeuvred through tight areas.



It is STRONGLY RECOMMENDED that the operator lead the Transpak, rather than “pushing” the Transpak. This will ensure that the operator has a safe unobstructed view ahead. This will also make the Transpak easy to manoeuvre.

Charging

Ensure regular recharging of batteries (charging overnight after a day’s usage is recommended). Irregular charging may cause the batteries to prematurely fail.

Leaving a machine in storage without charge for periods greater than a month can also lead to premature battery failure. This is not covered under warranty.

For detailed charging procedures refer to Appendix 1.



Only use the battery charger supplied with this Transpak.

The automatic features of the supplied charger ensures that the sealed gel batteries are not overcharged, and only a minimum amount of gas, if any at all, are expelled during charging.

Maintenance

Batteries

If this unit is not being used for an extended period of time, it should be connected to the battery charger to check the battery level on a regular basis, and placed on charge overnight if required. This will ensure the batteries are kept in good condition.

The batteries are sealed and maintenance free. DO NOT attempt to open these batteries. If the unit is not charged as above, the batteries may be exhausted and have dropped below the charging threshold of the battery charger. The supplied charger cannot begin to charge the batteries unless they have a small amount of charge. If this occurs, contact Electrodrive or your local service agent.

A sign that the batteries need replacing is when they no longer hold charge.

Motor and transmission

The motor is a sealed unit and does not require regular maintenance.

Brakes

The dynamic braking system does not require regular maintenance.

Motor controller

This unit is not serviceable. Any difficulties experienced with speed control should be referred to Electrodrive.

Throttle lever

The throttle lever and cable do not require maintenance. Should the lever or cable suffer damage they should be replaced. If the handle loosens with wear, the hinge nut can be gently tightened. However, first confirm that the lever is in the correct position as it may need to be reset. (Test by squeezing the lever slightly. The Transpak should slowly move, release and the Transpak should completely stop).

Fuses

The control circuit is protected against inadvertent current over-loads. This fuse is located adjacent to the controller under the top cover.

Self-resetting circuit breaker

This Transpak is fitted with a self resetting circuit breaker in case of momentary over-load. This circuit breaker can be found beneath the top cover on the main electrical control panel. If the unit repeatedly over-loads, test the machine, as the motor may be damaged, and continued use could damage the unit further.

Warranty

Electrodrive Pty Ltd warrants that this product is free from defects in materials and workmanship for a period of twelve months from the date of dispatch from the Electrodrive plant.

If a defect is reported, Electrodrive will repair or replace the defective part, at its own discretion. This warranty does not apply if this unit has been misused, damaged, or modified in any way.

Please be aware that modifications and misuse will void your warranty. The following activities (including, but not limited to) are examples of these:

Unauthorised maintenance

- The machine is re-wired by an unauthorized service agent
- The motor controller is re-programmed by an unauthorized service agent
- There are modifications to the body or frame of the machine
- Use of non-specified parts
- The machine is serviced by an unauthorized service agent


Misuse

- Overloading the unit either during towing or lifting
- Carrying people or other foreign objects
- Exposed to rain or other precipitation, unless weatherproof option is installed
- Using the emergency back-off system to change direction regularly
- Exposed to a corrosive environment
- Driven off road—potholes, gravel, etc.
- Driven on slopes with a steeper gradient than 1:12
- Not being charged adequately
- Using the emergency stop button as an ON/OFF button

General wear items not covered under warranty

- Castors
- Drive wheels and motor brushes
- Hand grips

Appendix 1: Machine rating conditions



Model	Safe Working Load	Max Load
TRANSPAK500	500 kg	500 kg

The Transpak has been designed to move the rated weight capacity on a level firm surface. Variations in the working environment may impede the performance of this unit. Such parameters include (but are not limited to) the following:

- Ramps and sloped surfaces
- Soft surfaces (for example carpet)
- Slippery surfaces (gravel, water, oil on the ground, etc)



It is important that the Transpak IS NOT to be operated outside of the recommended conditions.

Appendix 2: Fault codes

Fault Code	Explanation	Causes
☼ ☼	Over-temperature cutback	Machine overloaded Park brake not releasing properly Short in motor or wiring High ambient temperature
☼ ☼☼	Throttle pot fault	Throttle pot wires open or shorted Faulty throttle pot
☼ ☼☼☼	Speed governor fault	Speed governor wires open or shorted Faulty speed governor pot
☼ ☼☼☼☼	Battery voltage too low	Battery voltage < 17V
☼ ☼☼☼☼☼	Battery voltage too high	Battery voltage > 36V
☼☼ ☼	Main contactor controller failure	
☼☼ ☼☼	Contactor driver fault	
☼☼☼ ☼	HPD present > 10 seconds	Throttle out of adjustment
☼☼☼ ☼☼	Park brake fault	Park brake coil open circuited Controller failure
☼☼☼ ☼☼☼	Pre-charge fault	Low battery voltage Controller failure
☼☼☼ ☼☼☼☼	Park brake fault	Park brake coil shorted Controller failure
☼☼☼ ☼☼☼☼☼	High pedal disable (HPD)	Throttle not in neutral when key switch turned on
☼☼☼☼ ☼	Current sense fault	Short in motor or wiring Controller failure
☼☼☼☼ ☼☼	Motor voltage fault	Short in motor or wiring Controller failure
☼☼☼☼ ☼☼☼	EEPROM fault	Controller failure
☼☼☼☼ ☼☼☼☼	Output section fault	Short in motor or wiring Controller failure

Appendix 3: Charging procedures for SLA batteries

- Always charge batteries when work is complete and the equipment is not required for use.
- Opportunity charging is NOT recommended. This can also shorten battery life.
- Never leave batteries in a discharged state as this will shorten the batteries life.
- For maximum battery life, a battery must be recharged to 100% capacity. Recharging less than 100% may result in premature battery failure. Batteries are not covered under warranty if they are not recharged properly.
- If batteries are disconnected from the machine and not used for lengthy periods of time, it is recommended to give them a maintenance charge once every two months.

Charging setup

- Ensure you have the correct charger for the batteries. The correct voltage and current is important to ensure the full life of the batteries.
- Check all connections are tight and in good condition.
- The green charger LED will illuminate to confirm charging is in progress.
- If charger lights do not come on, call your service technician.
- When charger is plugged in, drive function of machine is automatically inhibited.

During charging

- Ensure there is enough airflow to help keep the batteries as cool as possible.
- If the batteries are swollen turn off immediately and call your service technician.
- Always leave batteries on charge until the charge is COMPLETE. This is indicated when charger LED turns off.


Charger manual


Please read BA1105—Battery Charger Operating Manual for more information.

Appendix 4: Spare parts list

Part	Description	Part	Description
BA1000	Battery—12V 36 Ah	TX1010	Transaxle—V24 250W 85 RPM
BA1105	Charger—24V 7 Amp	WH1090	Drive wheel
CL1052	Tiller handle membrane loom	WP1049	Tiller handle—complete
CL1130	Loom—charger with socket	WP1875	Tiller post
CL1141	Loom—controller suit tiller	WP1875	Tiller post
EL1041	Battery leads blue/white		
EL1100	Blanking plug—13mm		
EL1910	Circuit breaker—40 Amp		
EL2110	Motor controller—Curtis 1228		
EL2339	Emergency reverse system		
EL2380	Emergency stop button		
EL2450	Fuse 1 Amp (charger) (3AG)		
EL2470	Fuse 10 Amp (control) (3AG)		
EL2500	Fuse holder panel mount		
EL2620	Horn button (optional)		
EL2630	Horn (optional)		
EL2720	Key switch with key		
EL2775	Membrane key pad		
EL2805	Hour meter 12–48V		
EL3010	Potentiometer—5k (internal)		
GM1370	Chain and link		
GM1810	Handgrip 7/8" x 5" —tiller		
GM2040	Spring—tiller handle position		
GM2051	Tiller pot spring		
GM2150	Throttle cable		
GM2170	Tiller pin—zinc plated		
GM2210	Tiller pin—zinc plated		
OQB150/ HZZP	Castor—150 mm		

Appendix 5: Wiring diagram





Link between pin 2 and 3 on charger plug, on charger

Copyright Electrodrive
PTY LTD
Not to be copied or
reproduced in
any way without written
permission

Key:

- Black
 - Blue
 - Brown
 - Green
 - Grey
 - Orange
 - Pink
 - Purple
 - Red
 - Tan
 - White
 - Yellow
- optional feature

Title **WIRING SCHEMATIC - TUG EVO**

Size B	Number M080	Revision A
-----------	----------------	---------------

Service log

Service recommendations

To ensure this equipment is kept in a safe and reliable condition, it is important to follow a preventative maintenance program. Maintain a log of the service work on the cards below, and always use an approved Electrodrive service agent to conduct the works. Approved service personnel will be provided with all necessary documents and components in service repair, including but not limited to, circuit diagrams, component part lists, descriptions, service checklists and spare parts.

6 month service

Date of service		Service agent	
Machine serial number			
Summary of works			
Next service due			

12 month service

Date of service		Service agent	
Machine serial number			
Summary of works			
Next service due			

18 month service

Date of service		Service agent	
Machine serial number			
Summary of works			
Next service due			

24 month service

Date of service		Service agent	
Machine serial number			
Summary of works			
Next service due			

30 month service

Date of service		Service agent	
Machine serial number			
Summary of works			
Next service due			

36 month service

Date of service		Service agent	
Machine serial number			
Summary of works			
Next service due			

42 month service

Date of service		Service agent	
Machine serial number			
Summary of works			
Next service due			

48 month service

Date of service		Service agent	
Machine serial number			
Summary of works			
Next service due			

54 month service

Date of service		Service agent	
Machine serial number			
Summary of works			
Next service due			

60 month service

Date of service		Service agent	
Machine serial number			
Summary of works			
Next service due			

Innovative mobility solutions and products

www.electrodrive.com.au